

Karosa Cursor (49+1+39)

Řidič				
1	2			
5	6			
9	10			
13	14			
17	18			
21	22			
Místo pro kočárek / vozík				
27	28			
29	30			
33	34			
37	38			
41	42			
45	46	47	48	49